



QUICK START

1 TURN ON

2 WAIT FOR 5 SECONDS

3 GO DETECTING

Q SEARCH MODES

COIN



Find coins from around the world while ignoring trash in parks and at the beach.

RELIC



Locate deep relics in fields and forests.

JEWELLERY




Recover precious jewellery no matter where it was lost.

CUSTOM



Customisable user mode, optimised to minimise trash.





CONTROLS

- 1 BACKLIGHT ON/OFF (540)
- 2 POWER ON/OFF
- 3 VOLUME ADJUST
- 4 ALL METAL*
- 5 PINPOINT
- 6 SENSITIVITY ADJUST
- 7 ACCEPT/REJECT
- B DISCRIMINATION PATTERN EDIT
- 9 SEARCH MODE
- 10 BLUETOOTH ON/OFF (540)
- 11 TARGET IDENTIFICATION GUIDE

DISPLAY

- 12 BATTERY LEVEL
- 13 BACKLIGHT INDICATOR (540)
- 14 BLUETOOTH ON/OFF (540)
- 15 VOLUME LEVEL
- 16 SENSITIVITY LEVEL
- 17 IRON BIAS INDICATOR
- 18 TARGET IDENTIFICATION NUMBER
- 19 DEPTH GAUGE
- **20** SEARCH MODES
- **21** DISCRIMINATION SEGMENTS
- **22** PINPOINT INDICATOR

* Long press for Iron Bias (540)